



**Figure S05.1 - 5V Link MAP Sensor Wiring**

**Note: Only use a +12V OR +5V supply. NEVER wire both at the same time.**



**Figure S05.2 - 12V Link MAP Sensor Wiring**

MAP Loom Wire Colours	
MAP Signal	White
Sensor Ground	Green
+12V	Red
+5V	Red/Blue